

# DCM230-2 MID Series

## DC Energy Meter



User Manual  
2024 V2.1

## Statements

All rights reserved. Without the written permission of the company, no paragraphs or chapters in this manual can be extracted, copied or reproduced in any form. Otherwise, the violator shall bear all consequences.

Eastron reserves all legal rights.

Eastron reserves the right to amend the product specifications in this manual without prior notice. Before placing an order, please contact our company or local agent to get the latest specifications.

# CONTENT

|   |    |
|---|----|
| DCM230-2 MID Series .....                         | 1  |
| Statements .....                                  | 1  |
| Version History .....                             | 1  |
| <b>Chapter 1. Introduction</b> .....              | 4  |
| 1.1 Product Introduction .....                    | 4  |
| 1.2 Model list .....                              | 4  |
| 1.3 Product Differents .....                      | 4  |
| 1.4 Unit Characteristics .....                    | 4  |
| <b>Chapter 2. Technical Parameters</b> .....      | 4  |
| 2.1 Technical parameters .....                    | 4  |
| 2.2 Communication .....                           | 5  |
| 2.3 Performance criteria .....                    | 6  |
| 2.4 Marking and Symbols .....                     | 7  |
| 2.5 Dimension and Installation .....              | 7  |
| 2.6 Line loss .....                               | 8  |
| 2.7 Wiring .....                                  | 4  |
| <b>Chapter 3. Operation</b> .....                 | 5  |
| 3.1 Installation display .....                    | 5  |
| 3.2 Button Functions: .....                       | 6  |
| 3.3 Scroll display .....                          | 7  |
| 3.4 Setup Mode .....                              | 10 |
| <b>Chapter 4. Modbus Protocol</b> .....           | 13 |
| <b>Chapter 5. Maintenance and Cleaning</b> .....  | 18 |
| <b>Chapter 6. Shunt</b> .....                     | 18 |
| <b>Chapter 7. Declaration of Conformity</b> ..... | 20 |

## Version History

| Version | Date       | Changes                   |
|---------|------------|---------------------------|
| 2.0     | 2024-11-22 |                           |
| 2.1     | 2025-06-10 | Add line loss explanation |

## Risk Reduction

### Information for Your Own Safety

This manual does not contain all of the safety measures operating the equipment (module, device) for different conditions and requirements. However, it does contain information which you must know for your own safety and to avoid damages. These information are highlighted by a warning triangle indicating the degree of potential danger.



#### Warning

This means that failure to observe the instruction can result in death, serious injury or considerable material damage.



#### Caution

This means hazard of electric shock and failure to take the necessary safety precautions will result in death, serious injury or considerable material damage.

### Qualified personnel

Operation of the equipment (module, device) described in this manual may only be performed by qualified personnel. Qualified personnel in this manual means person who are authorized to commission, start up, ground and label devices, systems and circuits according to safety and Regulatory standards.

### Proper handling

The prerequisites for perfect, reliable operation of the product are proper transport, proper storage, installation and proper operation and maintenance. When operating electrical equipment, parts of this equipment automatically carry dangerous voltages. Improper handling can therefore result in serious injuries or material damage.

- ✧ Use only insulating tools.
- ✧ Do not connect while circuit is live (hot).
- ✧ Do not connect the meter to a AC network.
- ✧ Place the meter only in dry surroundings.
- ✧ Do not mount the meter in an explosive area or expose the meter to dust, mildew and insects.
- ✧ Make sure the wires are suitable for the maximum current of this meter.
- ✧ Make sure the DC wires are connected correctly before activating the current/voltage to the meter.
- ✧ Do not touch the meter connecting clamps directly with metal, blank wire and your bare hands as you may get electrical shock.
- ✧ Make sure the protection cover is placed after installation.
- ✧ Installation, maintenance and reparation should only be done by qualified personnel.
- ✧ Never break the seals and open the front cover as this might influence the function of the meter, and will cause no warranty.
- ✧ Do not drop, or allow strong physical impact on the meter as the high precisely components inside may be damaged.
- ✧ Designed to be mounted inside of switchboards or cabinet on DIN RAIL

- ✧ This device must have a suitable sized Circuit Breaker feeding the Multi Function Energy Meter so it does not exceed the maximum rated current.
- ✧ The supply wiring of this device shall be suitable sized cable to match the installed circuit breaker.
- ✧ A Disconnection Device (Circuit Breaker) should be installed close to the Multi Function Energy Meter.
- ✧ The Disconnection Device shall be marked as the Disconnection Device for the Multi Function Energy Meter

**Disclaimer**

We have checked the contents of this publication and every effort has been made to ensure that the descriptions are as accurate as possible.

However, deviations from the description cannot be completely ruled out, so that no liability can be accepted for any errors contained in the information given. The data in this manual is checked regularly and the necessary corrections are included in subsequent editions. We are grateful for any improvements that you suggest.

## Chapter 1. Introduction

### 1.1 Product Introduction

Eastron DCM230-2 series DC energy meters are designed for measuring and monitoring in DC systems. The din rail DC energy meters can measure of important DC parameters: Voltage, current, power and energy etc. It also support bi-directional measurement with pulse output. All data in the meter are accessible via RS485 using Modbus RTU. The meter works with DC power supply. Input voltage range up to 1000V DC, and current inputs are flexible with DC shunt.

Non-mains-circuits.

### 1.2 Model list

| Model        | Shunt     | Voltage Range | Current Range    | Pulse Constant( Default) |
|--------------|-----------|---------------|------------------|--------------------------|
| DCM230-2-150 | 150A/75mv | 100V-1000V    | 1.5-30 ( 150 ) A | 100 imp/kwh              |
| DCM230-2-200 | 200A/75mv |               | 2.0-40 ( 200 ) A | 100 imp/kwh              |
| DCM230-2-300 | 300A/75mv |               | 2.5-50 ( 300 ) A | 10 imp/kwh               |
| DCM230-2-400 | 400A/75mv |               | 2.5-50 ( 400 ) A | 10 imp/kwh               |
| DCM230-2-600 | 600A/75mv |               | 2.5-50 ( 600 ) A | 10 imp/kwh               |

| Model        | Shunt     | Voltage Range | Current Range    | Pulse Constant( Default) |
|--------------|-----------|---------------|------------------|--------------------------|
| DCM230-3-150 | 150A/75mv | 100V-1000V    | 1.5-30 ( 150 ) A | 100 imp/kwh              |
| DCM230-3-200 | 200A/75mv |               | 2.0-40 ( 200 ) A | 100 imp/kwh              |
| DCM230-3-300 | 300A/75mv |               | 2.5-50 ( 300 ) A | 10 imp/kwh               |
| DCM230-3-400 | 400A/75mv |               | 2.5-50 ( 400 ) A | 10 imp/kwh               |
| DCM230-3-600 | 600A/75mv |               | 2.5-50 ( 600 ) A | 10 imp/kwh               |

### 1.3 Product Differents

The internal hardware of the DCM230-2 and DCM230-3 is identical; The difference in the shell is limited to the difference in the surface of the upper shell.

The difference between the DCM230-2 series /DCM230-3 series is only that the shunt is not the same.

### 1.4 Unit Characteristics

The Unit can measure and display:

- voltage
- Currents
- Power
- Active energy imported and exported

Pulse output indicates real-time energy measurement. An RS485 output allows remote monitoring from another display or a computer.

## Chapter 2. Technical Parameters

### 2.1 Technical parameters

|                  |                            |
|------------------|----------------------------|
| Voltage DC Input | Min.100V DC, Max. 1000V DC |
|------------------|----------------------------|

|                                  |  |
|----------------------------------|--|
| Auxiliary Supply                 | Min. 9V DC, Max. 40V DC  |
| DC Shunt Input                   | 75mV (default)   |
| Current Range                    | 1.5-30(150)A/2-40(200)A/2.5-50(300)A/2.5-50(400)A/2.5-50(600)A |
| Voltage loop power consumption   | ≤ 0.5W   |
| Current loop power consumption   | ≤ 72W / 48W / 36W / 24W / 18W                                  |
| Auxiliary loop power consumption | ≤ 2W   |
| AC voltage withstand             | 6.2KV DC   |
| Impulse voltage withstand        | 9.6kV - 1.2 / 50μS waveform                                    |
| Pulse output                     | 150A&200A-100imp/kWh 300A&400A&600A-10imp/kWh                  |
| Pulse duration                   | 60, 100 (default), 200mS                                       |
| Pulse output indicate            | Total kWh/ import kWh/ export kWh                              |
| Display                          | LCD with backlit   |
| Max. Reading                     | 999999.9999kWh   |
| Weight                           | 220g   |
| Standard                         | GB/T 33708-2017/ IEC62053-41                                   |
| Accuracy                         | Reactive energy : Class B EN50470-4 (MID version only)         |

## 2.2 Communication

### RS485 Output for Modbus RTU

For Modbus RTU, the following RS485 communication parameters can be configured from the Set-up menu:

**Baud rate** 1200,2400, 4800, 9600,19200 bps

**Parity** none (default)/odd/even

**Stop bits** 1 or 2

**RS485 network address** *nnn* – 3-digit number, 001 to 247

**Modbus™ Word order** Hi/Lo byte order is set automatically to normal or reverse. It cannot be configured from the set-up menu.

Set-up screens are provided for setting up the RS485 port.

### Pulse output

The unit provides a pulse output. The constant can be configured to below:

1000 imp/kWh

100 imp/kWh

10 imp/kWh

1 imp/kWh

Pulse width: 200/100(default)/60 ms.

Note: the relationship between pulse constant and CT1

| CT1 setting | Default pulse constant | Settable pulse constant |
|-------------|------------------------|-------------------------|
| 1 – 20      | 1000 imp/kWh           | 1000,100,10,1 imp/kWh   |
| 21 – 200    | 100 imp/kWh            | 100,10,1 imp/kWh        |
| 201 – 2000  | 10 imp/kWh             | 10,1 imp/kWh            |




\*when the CT setting on meter is 2000A, the default pulse constant is 10 imp/kWh and it can be set to 10 imp/kWh or 1 imp/kWh.

\*Over-current alarm: Alarm will happened when the current is over the CT1 value set on the meter. The Alarm LED will stay solid and the corresponding register value will be changed. The user can read this register through communication to determine whether an overcurrent alarm has occurred.

The pulse outputs can be set to generate pulses to represent Import kWh/ Export kWh/ total kWh.

The pulse output is passive type, complies with IEC62053-31 Class A.




ATTENTION: Pulse output must be fed as shown in the wiring diagram below. Scrupulously respect polarities and the connection mode. Opto-coupler with potential-free SPST-NO Contact. Contact range:5~27VDC Max. current Input:27mA DC.

## 2.3 Performance criteria

|  |  |
|--|--|
| Operating temperature                  | -40℃ to + 70℃  |
| Storage and transportation temperature | -40℃ to + 80℃  |
| Reference temperature                  | 23℃ ± 2℃   |
| Relative humidity                      | 0 to 95%, non-condensing                                   |
| Altitude                               | up to 2000m  |
| measuring category                     | CATII  |
| Mechanical Environment                 | M1   |
| Electromagnetic environment            | E2   |
| Degree of pollution                    | 2  |
| Protective Class                       | II   |
| Warm up time                           | 3S   |
| Din rail dimensions                    | 36x100x63 (WxHxD) DIN 43880                                |
| Mounting                               | DIN rail 35mm  |
| Ingress Protection                     | IP20 (Installed in an electrical cabinet with IP51 rating) |
| Material                               | Self-extinguishing UL94V-0                                 |
| Installation environment               | Dry environment  |

2.4 Marking and Symbols



| NO. | Symbol | Reference               | Description  |
|-----|--------|-------------------------|--|
| 1   |        | IEC60417-5031(2002-10)  | Direct current   |
| 2   |        | IEC60417-5032(2002-10)  | Alternating current  |
| 3   |        | IEC60417-5172(2003-02)  | Equipment protected throughout by DOUBLE INSULATION or REINFORCED INSULATION |
| 4   |        |                         | Caution, possibility of electric shock                                       |
| 5   |        | ISO 7000-0434b(2004-01) | Caution*   |

2.5 Dimension and Installation

Read these instructions carefully and look at the equipment to become familiar with the device before trying to install “HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH”

- The assembly and installation of electrical connections must be carried out by a person authorized to install electrical equipment.
- Apply appropriate personal protective equipment and follow safe electrical work practices applicable to local standards.
- Turn off all power supplying this device and the equipment in which it is installed before working on it.
- Always use a properly rated voltage sensing device to confirm that all power is off.
- Do not exceed the device’s ratings for maximum limits.
- Do not use this device for critical control or protection applications where human or equipment safety relies on the operation of the control circuit.
- Once installed, the enclosure can only touch the upper surface.
- Do not allow the total additive current flowing through the device to exceed maximum continuous current rating. Failure to follow these instructions will result in death or serious injury.

## 2.6 Line loss

**Define:** line loss impedance is a result of the impedance of the wire between the positive terminal of the Mains supply and the device itself Rline1 and of the impedance of the wire between the second terminal of the device to the positive terminal of the meters shunt Rline2. Therefore the overall line loss impedance can be calculated as sum of both wire impedance.

**The calculation is described with the following:**

Line Loss Impedance = RlineLoss = Rline1 + R line2

Remark: In this document the line loss impedance is mentioned several times. This refers to the overall line loss impedance. The same applies for the configurable line loss impedance.

In the two-wire line loss measurement mode, the line loss energy is calculated as:

Line Loss power =  $p_{lineLoss}(t) = I_{shunt}^2(t) \cdot R_{line}$

Line Loss Energy =  $\int_0^t P_{lineLoss}(t) dt$

Note: The Value for Ishunt refreshes with a maximal period of 1500ms. The same value is applied for the integration constant for the line loss energy. The energy integration cycle is synchronized with the line loss power cycle.

## Import

For Import Energy Mode the register values for every point in time are given by:

Total Import Mains Energy = Total Import Device Energy + Total Import Line Loss Energy ,  
with  $R_{line} = (R_{line1} + R_{line2}) > 0$ , which is illustrated in Figure 28.

The exact calculation is given by:

Total Import Mains Power =  $P_{ImportMains}(t) = I_{shunt}(t) \cdot U_{terminal}(t)$

Total Import Device Power =  $P_{ImportDevice}(t) = P_{ImportMains}(t) - P_{lineLoss}(t)$


Total Import Mains Energy =  $\int_0^t P_{ImportMains}(t) dt$ .

Total Import Device Energy =  $\int_0^t P_{ImportDevice}(t) dt$ .



As prior mentioned the refreshment cycle of the base values for the respective power calculation and integration cycle of the resulting energy are synchronized.

## 2.7 Wiring

### Terminal Connection



### Shunt Connection






**\*\*Remarks:** If the customer needs to add a circuit breaker, it cannot be added between the signal lines of the DC- and shunt lines.



| Terminals               | Strip Length | Wire Range             | Torque | Model                  | Rated Voltage | Operating temperatur |
|-------------------------|--------------|------------------------|--------|------------------------|---------------|----------------------|
| Aux./RS485/Pulse/DC±/I± | 26-14 mm     | 0.5-1.5mm <sup>2</sup> | 0.4Nm  | WJ127-5.08-XXP-1YY-01A | 300V          | -40℃~+105℃           |
| shunt                   | 2000±20mm    | 2.1±0.1mm <sup>2</sup> |        | DCM230-2               | 1000V         | -40℃~+105℃           |

## Chapter 3. Operation

### 3.1 Installation display



When it is powered on, the meter will initialize and do self-checking.

|   |  |
|---|--|
|    | Full Screen (stay 2s)  |
|  | Software Version (stay 2s)<br><br>(This information is for reference only, in kind pervail.) |
|  | Program number   |


|  |   |
|--|---|
|   | Self-checking interface   |
|  | Total active energy(kWh)<br>Total=Import+ Export<br>Max read: 999999.9999 kWh |




### 3.2 Button Functions:





There are two buttons on the front panel.

|   |  |
|---|--|
|  | >Scroll the display for data checking.<br>>Changing option at Set-up mode<br>>Exit the Set-up mode |
|  | >Set-up mode entry<br>>Confirmation  |

### 3.3 Scroll display

After initialization and self-checking program, the meter displays the measured values. The default page is total kWh. If the user wants to check other information, please press the scroll button  on the front panel.

|   |  |
|---|--|
|    | <p>Total active energy(kWh)</p> <p>Total=Import+ Export</p> <p>Display format:</p> <p>6+4</p> <p>999999.9999 -&gt; 000000.0000</p> |
|   | <p>Partial resettable active energy</p> <p>Display format:</p> <p>6+4</p> <p>999999.9999 -&gt; 000000.0000</p>                     |
|  | <p>Voltage</p>   |














|  |   |
|--|---|
|  <p>A digital display showing the value 78.716 with the unit 'A' below it.</p>                        | <p>Current</p>  |
|  <p>A digital display showing the value 38.468 with the unit 'kW' below it.</p>                      | <p>Power</p> <p>Display format:</p> <p>&lt;1000 W: XXX W</p> <p>&lt;1000kW: XXX.XXX kW</p> <p>For other value: XXXX.XX kW</p> |
|  <p>A digital display showing the value 1000 with the unit 'C' to the right.</p>                    | <p>Pulse constant</p>   |
|  <p>A digital display showing the value 1000 with the unit 'A' below it and 'CT1' to the right.</p> | <p>CT1 Primary current</p>  |






































|   |                  |
|---|------------------|
|    | Meter address    |
|    | Baud rate        |
|  | Parity           |
|  | Software Version |

### 3.4 Setup Mode

To get into Set-up Mode, the user need press the “Enter” button  for 3 second.

| Page | Display   | Descriptions   |
|------|---|--|
| 1    |    | <b>Password</b><br>To get into Set-up mode, it asks a password confirmation. Default password: 1000<br>Use  and  to enter correct password.   |
| 2    |   | Keep pressing  for 3 second, the current selection will flash, use  and  to change the Modbus address. Options: 1~247<br>Keep press  for 3s to confirm the selection.                                    |
| 3    |  | Keep pressing  for 3 second, the current selection will flash, use  and  to change the Baud rate. Options: 1.2k, 2.4k, 4.8k, 9.6k ( default ), 19.2k<br>Keep press  for 3s to confirm the selection. |

|   |   |  |
|---|---|--|
| 4 |    | <p>Keep pressing  for 3 second, the current selection will flash, use  and  to change the Parity.</p> <p>Options: EVEN,ODD,NONE ( default )</p>                                   |
| 5 |   | <p>Keep pressing  for 3 second, the current selection will flash, use  and  to change the type of Pulse Output.</p> <p>Options: total kWh, IMP kWh, EXP kWh</p>                   |
| 6 |  | <p>Keep pressing  for 3 second, the current selection will flash, use  and  to change the pulse width.</p> <p>Options: 60, 100, 200, unit: ms</p>                           |
| 7 |  | <p>Keep pressing  for 3 second, the current selection will flash, use  and  to change the DIT(Demand Integration Time).</p> <p>Options: 0,5,8,10,15,20,30,60( default)</p> |

|    |   |   |
|----|---|---|
| 8  |    | <p>Use  to select the scroll display time option.</p> <p>Keep pressing  for 3 second, the current selection will flash, use  and  to enter the options: 0~60s.</p> <p>Default: 0 s, represent do not scroll display</p>        |
| 9  |    | <p>Use  to select the backlit time option. Keep pressing  for 3 second, the current selection will flash, use  and  to enter the options: 0,5,10,20,30,60 minutes. 0 means the light is always on.</p> <p>Default: 60 minutes</p> |
| 10 |   | <p>Use  to select the Password option. Keep pressing  for 3 second, the current selection will flash, use  and  to enter the new password. The range is from 0001 to 9999.</p> <p>Default: 1000</p>                        |
| 11 |  | <p>Shunt wiring</p> <p>Use  to select the shunt connection option. Keep pressing  for 3 second, the current selection will flash, use  to choose the connection way.</p> <p>Option: N, P<br/>N: Negative type (default)<br/>P: Positive type</p>   |

Keep pressing button  to exit the set-up mold.

|                          |        |                        |
|--------------------------|--------|------------------------|
| For example, to request: | Amps 1 | Start address=0006     |
|                          |        | No. of registers =0002 |
|                          | Amps 2 | Start address=0008     |
|                          |        | No. of registers=0002  |

| Address<br>(Register) | DCM230 Input Register<br>Parameter   |                   |                |       | Modbus<br>Protocol Start<br>Address Hex |            |
|-----------------------|--|-------------------|----------------|-------|---|------------|
|                       | Description  | Length<br>(bytes) | Data<br>Format | Units | Hi<br>Byte                              | Lo<br>Byte |
| 30001                 | Line to neutral volts.   | 4                 | Float          | V     | 00                                      | 00         |
| 30007                 | Current.   | 4                 | Float          | A     | 00                                      | 06         |
| 30013                 | Active power.  | 4                 | Float          | W     | 00                                      | 0C         |
| 30073                 | Import active energy   | 4                 | Float          | kWh   | 00                                      | 48         |
| 30075                 | Export active energy   | 4                 | Float          | kWh   | 00                                      | 4A         |
| 30085                 | Total system power demand  | 4                 | Float          | W     | 00                                      | 54         |
| 30087                 | Maximum total system power demand  | 4                 | Float          | W     | 00                                      | 56         |
| 30343                 | Total active energy  | 4                 | Float          | kWh   | 01                                      | 56         |
| 30385                 | Resettable partial kWh   | 4                 | Float          | kWh   | 01                                      | 80         |
| 316385                | Line to neutral volts.   | 4                 | Float          | V     | 40                                      | 00         |
| 316387                | Current.   | 4                 | Float          | A     | 40                                      | 02         |
| 316389                | Active power.  | 4                 | Float          | W     | 40                                      | 04         |
| 316391                | Import active energy   | 4                 | Float          | W     | 40                                      | 06         |
| 316393                | Emport active energy   | 4                 | Float          | W     | 40                                      | 08         |
| 316395                | Total system power demand  | 4                 | Float          | kWh   | 40                                      | 0A         |
| 316397                | Maximum total system power demand  | 4                 | Float          | kWh   | 40                                      | 0C         |
| 316399                | Total active energy  | 4                 | Float          | kWh   | 40                                      | 0E         |
| 316401                | Current resettable total active energy   | 4                 | Float          | kWh   | 40                                      | 10         |
| 316403                | Current overload alarm<br>00 00 means no alarm<br>00 01 means Current overload alarm | 2                 | Hex            | None  | 40                                      | 12         |

Note:

(1): The method of power demand calculation is: Import- Export. When the import and export powers appear in the demand period, the import power subtract the export power during data processing.

(2) The red marked are commonly used registers which allow users to read continuously at one time.

## Holding registers

Holding registers are used to store and display instrument configuration settings. All holding registers not listed in the table below should be considered as reserved for manufacturer use and no attempt should be made to modify their values.

The holding register parameters may be viewed or changed using the Modbus Protocol. Each parameter is held in two consecutive 4X registers. Modbus Protocol Function Code 03 is used to read the parameter and Function Code 10 is used to write. Write to only one parameter per message.

| Address Register | Parameter               | Modbus Protocol Start Address Hex |          | Valid range   | Mode |
|------------------|-------------------------|-----------------------------------|----------|---|------|
|                  |                         | High Byte                         | Low Byte |   |      |
| 40003            | Demand Period           | 00                                | 02       | Write demand period: 0~60 minutes, default 60.<br>Setting the period to 0 will cause the demand to show the current parameter value, and demand max to show the maximum parameter value since last demand reset.<br><b>Length : 4 byte</b><br><b>Data Format : Float</b>  | r/w  |
| 40005            | Slide time              | 00                                | 04       | Default 1, min.<br>Range : 1 ~ (Demand Period -1).<br><b>Length : 4 byte</b><br><b>Data Format : Float</b>  | r/w  |
| 40013            | Pulse Width             | 00                                | 0C       | Write pulse1 on period in Milliseconds: 60, 100 or 200, default 100.<br><b>Length : 4 byte</b><br><b>Data Format: float</b>   | r/w  |
| 40019            | Network Parity and Stop | 00                                | 12       | Write the network port parity/stop bits for MODBUS Protocol, where:<br>0 = 1 stop bit and none parity, default.<br>1 = 1 stop bit and even parity.<br>2 = 1 stop bit and odd parity.<br>3 = 2 stop bit and none parity. Requires a restart to become effective.<br><b>Length : 4 byte</b><br><b>Data Format : Float</b> | r/w  |
| 40021            | Modbus address          | 00                                | 14       | Write the Modbus address<br>Address: 1 to 247 for MODBUS Protocol, default 1.   | r/w  |

|       |                          |    |    |   |     |
|-------|--------------------------|----|----|---|-----|
|       |                          |    |    | Requires a restart to become effective.<br><b>Length : 4 byte</b><br><b>Data Format : Float</b>   |     |
| 40023 | Pulse constant           | 00 | 16 | Options:<br>0 means 1000 imp/kWh<br>1 means 100 imp/kWh<br>2 means 10 imp/kWh<br>3 means 1 imp/kWh<br><b>4 means 10K imp/kWh</b><br><b>Length : 4 byte</b><br><b>Data Format: float</b> | r/w |
| 40025 | Password                 | 00 | 18 | Write password for access to protected registers.<br><b>Length : 4 byte</b><br><b>Data Format : Float</b>   | ro  |
| 40029 | Baud Rate                | 00 | 1C | Options:<br>0 means 2400 bps<br>1 means 4800 bps<br>2 means 9600 bps<br>3 means 19200 bps<br>5 means 1200 bps<br>Default: 2<br><b>Length : 4 byte</b><br><b>Data Format: float</b>      | r/w |
| 40051 | CT1                      | 00 | 32 | <b>CT1 range 1-9999A</b><br><b>Length : 4 byte</b><br><b>Data Format : Float</b>  | R/w |
| 40059 | Auto-scroll display time | 00 | 3A | Range: 0~60s.<br>0 means no scroll<br>Default:0<br><b>Length : 4 byte</b><br><b>Data Format : Float</b>   | r/w |
| 40061 | Backlit time             | 00 | 3C | Options: <b>0,5,10,20,30,60</b> minutes<br>0 means the backlit always on<br>Default: 60<br><b>Length : 4byte</b><br><b>Data Format : Float</b>  | r/w |
| 40087 | Pulse output type        | 00 | 56 | Options:<br>1 means Import active energy<br>2 means total active energy<br>4 means Export active energy<br>Default: 2<br><b>Length : 4 byte</b><br><b>Data Format: float</b>            | r/w |

|        |                                |    |    |   |     |
|--------|--------------------------------|----|----|---|-----|
| 48193  | Connection<br>method of shunt  | 20 | 00 | Setting on shunt connection.<br>Option:<br>00 4E means Negative type (default)<br>00 50 means Positive type<br><b>Length: 2 byte</b><br><b>Data Format: Hex</b> | r/w |
| 461457 | Reset                          | F0 | 10 | 00 00: Reset Maximum Demand<br>00 03: Reset Partial Energy<br><b>Length : 2 byte</b><br><b>Data Format:Hex</b>  | wo  |
| 463777 | Energy<br>Measurement<br>model | F9 | 20 | Options:<br>00 01: Total=Import<br>00 02: Total=Import+Export<br>00 03: Total=Export<br><b>Length : 2 byte</b><br><b>Data Format: Hex</b>                       | r/w |
| 464513 | Serial number                  | FC | 00 | <b>Serial number</b><br><b>Length: 4 byte</b><br><b>Data Format: unsigned int32</b><br><b>Note: Only read</b>   | ro  |
| 464515 | Meter code                     | FC | 02 | <b>Length : 2 byte</b><br><b>Data Format : hex</b><br><b>Note: Only read</b>  | ro  |
| 464641 | Software<br>version            | FC | 80 | <b>Length : 2 byte</b><br><b>Data Format : Hex</b>  | ro  |
| 464643 | Hardware<br>version            | FC | 82 | <b>Length : 2 byte</b><br><b>Data Format : Hex</b>  | ro  |
| 464645 | Display version                | FC | 84 | <b>Length : 2 byte</b><br><b>Data Format : Hex</b>  | ro  |
| 464647 | Program<br>number              | FC | 86 | <b>Length : 2 byte</b><br><b>Data Format : Hex</b>  | ro  |
| 464649 | CRC code                       | FC | 88 | <b>Length : 4 byte</b><br><b>Data Format : Hex</b>  | ro  |
| 464651 | Serial2 number                 | FC | 90 | <b>Length : 20 byte</b><br><b>Data Format : ascii</b>   | ro  |

**Eg:**

## 1. read CT1

Tx: 01 03 00 32 00 02 crc crc

Rx:01 03 04 43 48 00 00 crc crc

Tx explanation:

01:Meter Addr

03:Function code

00 32:modbus protocol start address



00 02:Length/2

Rx explanation:

01:Meter Addr

03:Function code

04:Length

43 48 00 00:CT1 value (need to convert float :200)

## 2. Write CT1

Tx: 01 10 00 32 00 02 04 43 48 00 00 crc crc

Rx:01 10 00 32 00 02 crc crc

Tx explanation:

01:Meter Addr

10:Function code

00 32:modbus protocol start address

00 02:Length/2

04 :Length

43 48 00 00:(CT=200 is float need to convert hex:43 48 00 00 )

Rx explanation:

01:Meter Addr

10:Function code

00 32:modbus protocol start address

00 02:Length/2

## Chapter 5. Maintenance and Cleaning


In normal use, little maintenance is needed. As appropriate for service conditions, isolate electrical power, inspect the unit and remove any dust or other foreign material present. Periodically check all connections for freedom from corrosion and screw tightness, particularly if vibration is present. The front of the case should be wiped with a dry cloth only. Use minimal pressure, especially over the viewing window area. If necessary wipe the rear case with a dry cloth. If a cleaning agent is necessary, isopropyl alcohol is the only recommended agent and should be used sparingly. Water should not be used. If the rear case exterior or terminals should be contaminated accidentally with water, the unit must be returned to EASTRON for inspection and testing.

Check whether the cable of the diverter is loose periodically.







Check the interior of the box regularly to check the wiring status.

Our shunt is matched, if there is a problem, do not replace without permission, please contact us.

## Chapter 6. Shunt



| FL-2 Series   |                      |          |               |                      |
|---------------|----------------------|----------|---------------|----------------------|
| Primary Input | Rated Voltage Output | Accuracy | Dimension(mm) | Dimension(shell)(mm) |
| 150 A         | 75 mV                | 0.2%     | 22x149x21     | 83.12X175.52X48.5    |
| 200 A         | 75 mV                | 0.2%     | 22x149x21     | 83.12X175.52X48.5    |
| 300 A         | 75 mV                | 0.2%     | 26x149x21.5   | 83.12X175.52X48.5    |
| 400 A         | 75 mV                | 0.2%     | 38x149x21.5   | 83.12X175.52X48.5    |
| 600 A         | 75 mV                | 0.2%     | 62x149x21.5   | 83.12X175.52X48.5    |

|   |   |
|---|---|
|  <p>Technical drawing of the ESFL-2-150 component. The side view shows a width of <math>5.5 \pm 0.5</math> and a height of <math>21 \pm 1</math>. The front view shows a total width of <math>149 \pm 1</math>, with internal dimensions of <math>73 \pm 0.5</math> and <math>119 \pm 0.5</math>, and a height of <math>22 \pm 1</math>.</p>     |  <p>Technical drawing of the ESFL-2-200 component. The side view shows a width of <math>5.5 \pm 0.5</math> and a height of <math>21 \pm 1</math>. The front view shows a total width of <math>149 \pm 1</math>, with internal dimensions of <math>73 \pm 0.5</math> and <math>119 \pm 0.5</math>, and a height of <math>22 \pm 1</math>.</p>    |
| ESFL-2-150  | ESFL-2-200  |
|  <p>Technical drawing of the ESFL-2-300 component. The side view shows a width of <math>5.5 \pm 0.5</math> and a height of <math>21.5 \pm 1</math>. The front view shows a total width of <math>149 \pm 1</math>, with internal dimensions of <math>124 \pm 0.5</math> and a height of <math>26 \pm 1</math>.</p>                               |  <p>Technical drawing of the ESFL-2-400 component. The side view shows a width of <math>5.5 \pm 0.5</math> and a height of <math>21.5 \pm 1</math>. The front view shows a total width of <math>149 \pm 1</math>, with internal dimensions of <math>73 \pm 0.5</math> and <math>124 \pm 0.5</math>, and a height of <math>38 \pm 1</math>.</p> |
| ESFL-2-300  | ESFL-2-400  |
|  <p>Technical drawing of the ESFL-2-600 component. The side view shows a width of <math>5.5 \pm 0.5</math> and a height of <math>21.5 \pm 1</math>. The front view shows a total width of <math>149 \pm 1</math>, with internal dimensions of <math>73 \pm 0.5</math> and <math>124 \pm 0.5</math>, and a height of <math>62 \pm 1</math>.</p> |  <p>Technical drawing of the Shunt enclosure. The top view shows a width of <math>175.5 \pm 0.15</math> and a height of <math>48.5 \pm 0.15</math>. The front view shows a height of <math>83.1 \pm 0.15</math>.</p>  |
| ESFL-2-600  | Shunt enclosure   |

## Chapter 7. Declaration of Conformity

We Zhejiang Eastron Electronic Co., Ltd.

Declares under our sole responsibility as the manufacturer that the single phase multifunction electrical energy meter DCM230-2/DCM230-3 series correspond to the production model described in the EU-type examination certificate and the requirements of the Directive 2014/32/EU. Type examination certificate number 0598/MID/B/24/028. Identification number of the Notified Body: 0598.

If you have any question, please feel free to contact our sales team.

### **Eastron Electronic Co., Ltd.**

No. 52, Dongjin Road, Nanhu, Jiaxing, Zhejiang, China

Tel: +86-573-83698881 Fax: +86-573-83698883

Email: [sales@eastrongroup.com](mailto:sales@eastrongroup.com)

[www.eastrongroup.com](http://www.eastrongroup.com)

